


Doc.nr.: 9.16.241E

Date: 08-03-2023


## ML120 with Dunkermotor BG-series

Hook-up diagram

## Controller power supply via junction box 7.03.751 Cable junct. Dunker DB9



Controller power supply via powered fieldbus
7.03.749 Cable junct. Dunker M8 4p male






When connecting the system to other devices, be sure that the integrity of the shielding is not affected. Do not use unshielded wire terminals. Keep unconnected wire ends isolated.

## Power supply Junction box

Hook-up diagrams



Note: Pump (BG45) needs:24 Vdc (min. 4A) Power supply

Fieldbus hook-up for mini CORI-FLOW ML120 can be downloaded at:

https://www.bronkhorst.com/int/products/liquid-flow/mini-cori-flow/ml120v00/